Dynamic load balancing

MANUAL



Table of contents

1. Safety

2. Introduction of Beaen Load Balancing

3. Description
3.1 Charging station Component
3.2 DLB System Component

4. Technical Data
4.1 Charger Data
4.2 DLB system Data

5. Transportation&Storage
5.1 Transportation
5.2 Storage

6. Installation
6.1 Installation of Charging Station
6.2 Installation of DLB system

7. Load Balancing Configuration

8. Menu Navigation

9. Introduction to Load Balancing Interface Display

10. DLB System Indicator Status

11. Introduction to the Interface Display of Load Balancing Charging Stations

1. Safety

Please make sure you have fully read and understood the instructions in the manual before you start installing or using the product. If you fail to follow the instructions from the manual you can put persons, surroundings, the environment and the product at risk. Store the manual in a safe place for future reference.

Always comply with the information, safety and warning signs. Any damage caused directly to the product and keep the information in a legible condition.Always comply with any applicable laws and regulations that have been enacted for the in the manual.

Security Warning

- **ATTENTION**

Non-compliance with the operating instructions can cause serious consequences.

Manufacturer does not assume any liability for damage caused by disregarding operating instructions or other negligent handling of the device.

High voltage can cause fire hazard. Never use the device if the housing is damaged or opened. Do not touch the plug with wet hands. Never pull the cable to disconnect the plug from the socket outlet, and make sure not to experience in a similar degree of knowledge.

- **IMPORTANT SAFETY INSTRUCTIONS WARNING!**

The product should only be installed, serviced and maintained by authorized electricians who have read and understood the entire instruction manual. All applicable local, national and international regulations for electrical installations must be respected.

Be careful. Check if the charger has visible damage like cracks or damaged product.

Make sure that all safety facilities and connections are available, properly installed and working. Do not use the charger if any safety facility is defective or has been removed.

Make sure that the local voltage, frequency and the electrical current conditions of the device meet the specifications before the device is powered on. It's important to observe the maximum power output of the charging station.

Before switching on the device, please confirm that the device is properly grounded to avoid unnecessary accidents. If a grounded fault occurs, it is assumed that the cable connected to the EV may be the cause of the fault. Please check the cable before further inspecting the device.

Please insulate the unnecessarily exposed metal parts of all tools to prevent them from short circuits that may cause injuries to the body or fire.

Do not modify, retrofit, or change any part by yourself under any circumstances.

Please do not operate the device in any way. Please take good care of children to ensure that they will not play with the device as a toy nor put fingers into the charging connector when the power plug is connected.

The circuit to which the charger is to be connected must be equipped with a residual current protective device.

- **NOTE**

Please do not use it for other purposes except electric car charging. Do not try to disassemble the charger by yourself. If you need to repair the charger, please find the professional repair personnel. Improper repair will put the user's life at risk.

2. Introduction of Besen Load Balancing

- Household load balancing adopts the one-to-one wireless communication between the charging station and charging socket, and real-time data.
- The DLB System works as the master device, and the charging station as the slave device.
- Users can view the Total Current through the DLB System to know the current consumption of household appliances.
- The user needs to set the current parameter MAINS of the DLB System.

When the power consumption peaks, the charging station will reduce the charging current, and when the power consumption is low, the charging station will increase the charging current.

3. Description

This Charger is a Mode 3 charger for charging electric vehicles (EV) that complies with the IEC 61851 standard.

This Charger is equipped with several features to optimise power consumption and charging performance.

Charging Load Balancing

- The load balancing system consists of DLB System and charging stations.
- Use to-one wireless communication between DLB System and charging stations.
- DLB System which is suitable for detection of household appliances.
- The load balancing system collects the current consumption of household appliances and transmits the data to the charging station in real time.

The DLB System is suitable for detection three-phase and single-phase.

Current parameters and status can be configured through the DLB display and buttons of the DLB System.

3.1 Charging station Component





3.2 DLB System Component



4. Technical Data

4.1 CHARGING STATION DATA

Mode C	Mode 4
Three Mode: Single / Three Phase	Three Mode: Single / Three Phase
Installation Method: Wall/Stand	Installation Method: Wall/Stand
Mode C (with cable)	Mode 4 (with cable)
Certificate: CE	Certificate: CE
IP Rating: IP55	IP Rating: IP55
Rated Voltage: 230/400VAC±10% 50Hz±5%	Rated Voltage: 230/400VAC±10% 50Hz±5%
Rated Current: 16/32A	Rated Current: 16/32A
Maximum Power: 22KW/7KW/3.5KW	Maximum Power: 22KW/7KW/3.5KW
Cable Length: 5m (Optional)	Cable Length: 5m (Optional)
Enclosure Material: ABS + PC	Enclosure Material: ABS + PC
Start Mode: Button(default) / RFID(Optional) / APP via Bluetooth (Optional)	Start Mode: Button(default) / RFID(Optional) / APP via Bluetooth (Optional)

4.2 DLB System Data

DLB System power supply:	Input:85-264V AC 50/60Hz
Current transformer:	detection range is 150A, accuracy 2.5 %
Wireless frequency:	433MHz/868MHz
Housing dimensions:	86 * 86 * 28mm
Working temperature:	-20℃ ~ +55℃

5. Transportation&Storage

5.1 Transport

Transport the product in the original packaging, in suitable stable/vertical packaging that prevents adequate protection from vibrations, bumps, moisture, dust, and sketch.

Be careful not to tilt the product and avoid the product from overturning during transport. While transporting,excessive vibrations could impact wire connections and cause the charging station to fail.

5.2 Storage

Always disconnect the product from the power supply when storing the product.

Store the product in environmental conditions within the limits stated in chapter 3 Technical Data.

Store the product in a location that is protected from direct sunlight.


Store the product in a location that is protected from direct sunlight.

Do not store anything on top of the product.

6. Installation

6.1 Charging Station Installation

(MODE C - With cable)



(MODE C - With socket)



6.2 Load Balancing System Installation

Wiring Instructions (The diagram below illustrates a three-phase device.)



- The DLB System is installed in the distribution box, and the antenna should be installed outside the distribution box.
- The charging station is installed under the load balancing cable on the household appliance.
- The current transformer is installed at the front end of the input busbar cables, enabling the detection of the total current consumption of household appliances.
- The incoming cable of the charging station is connected to the corresponding L, N, PE interface according to the label.
- Charging stations need to be protected by circuit breakers and residual current circuit breakers.

Note: For three-phase setups, the CLS box detects the phase with the highest consumption and sets the charging current accordingly.

If it is unstable, the charging current may be limited to a lower value. In this case, the charging current is automatically adjusted to the lowest available 16A per phase.

Consequently, the charging station will charge at a maximum current of approximately 16A.

7. Load Balancing Configuration



8. Menu Navigation

- Status display& Total Current: The transformer detects the current and displays the total current consumed by all household appliances in real time.
- Status display& Available Current: According to the RMNS parameter setting, the remaining current that the load can safely use and is displayed.
- Status display& Set: WIFI has been connected.
- Status display& Set: WIFI is not connected.
- Parameter setting &RMNS: set the maximum carrying current of the mains busbar, the default current is 100A.
- Parameter setting &Mains: the charging station of the black machine, sum the device current of the charging station and the total current detected by the current transformer, and need to be set.
- Parameter setting &Bluetooth: DLB System Bluetooth name, APP connection to cancel the Bluetooth name and factory settings, no need to set.

9. Introduction to Load Balancing Interface Display



10. DLB System Indicator Status

Status	Charging	WiFi	Bluetooth
DLB System Normal Operation	Flashing	off	off
DLB System Function Abnormal	off	Flashing	off
Offline	off	off	Flashing
Not networked	off	off	Steps on

11. Introduction to the Interface Display of Load Balancing Charging Stations



1. Set button current, busbar usage current, busbar usage power, busbar usage percentage
2. Residential usage current
3. Residential usage power
4. Residential usage percentage
5. Charging stations rated current
6. Charger ID

7. Wireless networking status
8. Charging amount, charging time
9. Charging status
10. Charging current
11. Charging power
12. Charging temperature
13. Working temperature





For various faults, the system cannot recover automatically. In order to remind the user that the fault has occurred, the system will automatically count down for 10 seconds to restart after the user disconnects the charging gun.

Special Scenarios

- **Unbalanced current:** Some vehicles cannot cooperate with charging stations for dynamic current adjustments. In such cases, vehicles typically only have three gears for current adjustments, such as 6A, 16A, 32A, and don't support adjustments for dynamic balance during charging.

Therefore, it's essential to verify whether your vehicle supports these current regulations when using dynamic balance charging stations.